




A-EWR Fitting Instructions

fig1. ① Hold the round metal lever and push it slightly backwards to release the lock. ② Swing the lever down.

fig2. ③ Insert the V-Mount of the A-EWR down into V-Mount of the ENDURA Battery.

fig3. ④ Swing the lever upward to lock the bracket in place.

Note : The Wireless Receiver can then be fitted using the four standard format locating bosses (enclosed screws M3×5mm×2 & M4×5mm×2).
Alternately these bosses can be unscrewed to present a flat surface to attach the Wireless Receiver using 'Velcro'etc.



FOR SALES AND SERVICE CONTACT

I-D-X Company Ltd. : 6-28-11 Shukugawara, Tama-ku, Kawasaki-shi, Kanagawa-ken 214-0021, Japan

Tel : 81-44-850-8801 Fax : 81-44-850-8838 E-mail : idx.japan@idx.tv

I-D-X System Technology : 1602 Lockness Place, Torrance, CA 90501 U.S.A. Tel: 1-310-891-2800 Fax: 1-310-891-3600 E-mail : idx.usa@idx.tv

I-D-X Technology Europe Ltd. : Unit 34, Metropolitan Centre, 3 Taunton Road, Greenford, Middlesex UB6 8UQ, England

Tel : 44-20-8813-1666 Fax : 44-20-8813-1777 E-mail : idx.europe@idx.tv




A-EWRの取り付け方法

図1、①右下の丸い部分を持って、押しながらロックを外し、②下げて下さい。

図1、③A-EWRのマウント部をEnduraバッテリーのマウント部に上から差し込み、下まで挿入して下さい。

図1、④図のように人差し指と親指で平の部分をはさむように持ち、ロックプレートをしっかり上まで止めて下さい。

* 付属ネジ(M3X5 2本)(M4X5 2本)を使用してワイヤレス機器を取り付けて下さい。



お問合せは当社営業部へ

株式会社 アイディーエックス 本 社 : 〒214-0021 神奈川県川崎市多摩区宿河原5-13-1 Tel : 044-932-4462 Fax : 044-932-4487
Home Page : <http://www.idx.tv> E-mail : idx.japan@idx.tv

※当製品の保証期間はご購入後6ヶ月となります。※製品に保証書は付いておりませんが製品番号で弊社にて管理しております。※製品に関するご要望、ご質問は上記までご連絡下さい。